

Upgraded coat rack assembly instructions

List of product parts

Ax2		Bx4	
Cx2		Dx2	
Ex1	①x14	②x12	③x2
④x2			

1

2

3