ASSEMBLY INSTRUCTION

1.



2.



Ax1	Bx4	Cx20	Dx1	Ex4